

SHIMANO STEPS

SHIMANO Total Electric Power System

SC-E6100 User's Manual

Cycle Computer

CONTENTS

IMPORTANT NOTICE	3
Important Safety Information	3
NOTICE	4
Regular inspections before riding the bicycle	4
Booklet Structure	6
Names of parts	7
Notation method for operations	8
Installing and removing the cycle computer	9
Removing	9
Installing	9
Basic operation	10
Turning the power ON/OFF	10
Viewing the screen.....	11
Battery level indicator	12
Turning the light ON/OFF	13
Switching the traveling data display	14
Resetting the traveling distance.....	15
Setting menu	16
Switching to the setting menu	16
Returning to the main screen from the setting menu screen [Exit]	16
Setting the time [Clock]	17
Turning the operation sound ON/OFF [Beep]	17
Setting the display	18
Backlight setting [Backlight].....	18
Setting the screen brightness [Brightness]	18
Switching the font color [Font color]	18
Switching the display language [Language]	18
Changing the unit of the speed and distance [Unit]	19
Matching the displayed speed with another device [Display speed]	19
Resetting the settings [Clear].....	19
Setting the assist bicycle function.....	21
Setting the gear position when starting from a stop [Start mode]	21
Dynamically changing the riding comfort [Assist customize]	21

Indicating the optimal gear shifting timing via an icon [Shifting advice].....	22
Adjusting auto gear shifting [Shift timing]	22
Wireless connection	23
2.4 GHz digital wireless systems	23
ANT connection.....	23
Connection method	23
Bluetooth® LE connection.....	23
Connection method	23
Wireless system specifications	23
E-TUBE PROJECT	23
Items configurable in E-TUBE PROJECT	24
Troubleshooting	25
Recovering from the RD protection function [RD protection reset]	25
Gear shifting adjustment with the electronic gear shifting unit [Adjust]	25
Error/warning indication	26
Error indication	26
Warning indication	26
When a problem occurs	27

IMPORTANT NOTICE

- Contact the place of purchase or a distributor for information on installation, adjustment, and replacement of the products which are not found in the user's manual. A dealer's manual for professional and experienced bicycle mechanics is available on our website (<https://si.shimano.com>).
- Please observe the appropriate rules and regulations of the country, state or region in which you conduct your business as a dealer.
- The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by SHIMANO INC. is under license. Other trademarks and trade names are those of their respective owners.

For safety, be sure to read this "user's manual" thoroughly before use, follow it for correct use, and store it so that it can be referenced at any time.

The following instructions must be observed at all times in order to prevent personal injury and physical damage to equipment and surroundings. The instructions are classified according to the degree of danger or damage which may occur if the product is used incorrectly.

DANGER

Failure to follow the instructions will result in death or serious injury.

WARNING

Failure to follow the instructions could result in death or serious injury.

CAUTION

Failure to follow the instructions could cause personal injury or physical damage to equipment and surroundings.

Important Safety Information

WARNING

- Do not disassemble or modify the product. This may cause the product to not operate correctly, and you may suddenly fall and be seriously injured.

Riding precautions

- Do not to pay excessive attention to the cycle computer display while riding. Doing so may result in an accident.
- Confirm that the light works before riding.

Safety precautions

- Be sure to remove the battery and charging cable before wiring or attaching parts to the bicycle. Failure to do so may cause an electric shock.
- Be sure to follow the instructions provided in the manuals when installing the product. It is recommended that you use SHIMANO genuine parts. Loose nuts or bolts and product damage may cause a sudden accident such as a fall and lead to serious injury.
- Do not leave this product in an extremely high temperature surrounding environment such as in a closed vehicle on a hot day, or near a heater. That can result in an explosion of the incorporated battery or the leakage of flammable liquid or gas from it.
- Do not subject this product to extremely low air pressure. That may result in an explosion of incorporated battery or the leakage of flammable liquid or gas from it. Transporting this product by air is not a problem.

Disposal precautions

- Observe all federal, state and local environmental regulations when disposing of this product, because it incorporates a battery. Disposal of this product into fire or a hot oven, or mechanically crushing or cutting of it, that can result in an explosion of the incorporated battery.

CAUTION

Riding precautions

- Observe the instructions in the manual for the bicycle in order to ride safely.

Safety precautions

- Never modify the system. Doing so may cause a system error.
- Use the product under the supervision of someone responsible for safety and upon receiving usage instructions. Do not allow anyone with reduced physical, sensual, or mental capacity, or those without experience or knowledge, to use the product, including children.

- Do not allow children to play near the product.

NOTICE

Safety precautions

- If any malfunction or trouble occurs, consult the place of purchase nearest you.
- Be sure to attach caps to any unused connectors.
- For installation and adjustment of the product, consult a place of purchase.
- The components are designed to be fully waterproofed to withstand wet weather riding conditions; however, do not deliberately place them into water.
- Do not clean the bicycle with a high-pressure washer. If water gets into any of the components, operating problems or rusting may result.
- Do not turn the bicycle upside down. There is a risk of damage to the cycle computer and switch unit.
- Handle the components carefully, and avoid subjecting them to strong shock.
- Although the bicycle still functions as a normal bicycle even when the battery is removed, the light will not turn on if it is connected to the electric power system. Be aware that using the bicycle under these conditions will be considered non-observance of the road traffic laws in Germany.

Connection and communication with PC

A PC linkage device can be used to connect a PC to the bicycle (system or components), and E-TUBE PROJECT can be used to carry out tasks such as customizing single components or the whole system and updating firmware.

- PC linkage device: SM-PCE1/SM-PCE02
- E-TUBE PROJECT: PC application
- Firmware: Software inside each component

Connection and communication with smartphone

- It is possible to customize single components or the system and update firmware using the smartphone version of E-TUBE PROJECT after connecting the bicycle (system or components) to a smartphone via Bluetooth® LE.
- E-TUBE PROJECT: Application for smartphones
- Firmware: Software inside each component

Care and maintenance

- Contact the place of purchase for updates of the component software. The most up-to-date information is available on the SHIMANO website.
- Do not use thinner or other solvents to clean any of the components. Such substances may damage the surface.
- For any questions regarding methods of installation and maintenance, please contact your place of purchase.
- Products are not guaranteed against natural wear and deterioration from normal use and aging.
- For maximum performance we highly recommend SHIMANO lubricants and maintenance products.

Labels

- Some of the important information contained in this user's manual is also indicated on the device label.

Regular inspections before riding the bicycle

Before riding the bicycle, check the following items. If any problems are found, consult your place of purchase or a distributor.

- Does the drive train perform gear shifting smoothly?
- Are the components fixed securely and free from damage?
- Are the components securely installed to the frame/handlebar/stem, etc.?
- Do any abnormal noises occur while riding?
- Is there sufficient charge remaining in the battery?

FCC compliance information

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTICE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Booklet Structure

SHIMANO STEPS user's manuals are split among several booklets, as described below.

Be sure to read these user's manuals thoroughly before use, and follow them for correct use. Store the user's manuals so that they can be referenced at any time.

The latest user's manuals are available on our website (<https://si.shimano.com>).

- **SHIMANO STEPS user's manual**

This is the basic user's manual for SHIMANO STEPS. It contains the following content.

- SHIMANO STEPS quick guide
- How to operate assist bicycles that use flat handlebars, such as city, trekking, or MTB type bicycles
- Troubleshooting

- **SHIMANO STEPS user's manual for drop handlebar bicycles (separate booklet)**

This booklet describes how to operate assist bicycles that use a drop handlebar and are controlled using a dual control lever. This should be read along with the SHIMANO STEPS user's manual.

- **SHIMANO STEPS special battery and parts user's manual**

It contains the following content.

- How to charge and handle the SHIMANO STEPS special battery
- How to attach and remove the SHIMANO STEPS special battery to the bicycle
- How to use the satellite system on/off switch and satellite charging port
- How to read the battery LEDs when charging or during an error, and how to handle errors

- **Cycle computer user's manual (this document)**

It contains the following content.


- Basic operations of the cycle computer and how to configure settings
- Wireless communication method
- Cycle computer troubleshooting

- **Switch unit user's manual**

This is the assist switch and shifting switch user's manual. Describes switch unit operations.

Names of parts

This product is operated with the function button on the main body and the switch unit included in the assist bicycle.



The operation for each button/switch is indicated below.

Cycle computer	
Function Button*1	When riding: Switching traveling data display When setting: Switch screen or confirm setting changes
Power button	Main power ON/OFF
Light button	Light ON/OFF

*1 The operation performed when the button is held down differs according to whether a switch unit with an assist function assigned is connected.

- If a switch unit with an assist function assigned is connected: Display setting menu screen
- If a switch unit with an assist function assigned is not connected: Change assist mode

Switch unit (left) (default: for assist)		Switch unit (right) (default: electronic gear shifting)	
Switch-X	When riding: Increase assistance When setting: Move cursor or change setting	Switch-X	When riding: Shifting up
Switch-Y	When riding: Decrease assistance When setting: Move cursor or change setting	Switch-Y	When riding: Shifting down
Switch-A	When riding: Switching traveling data display When setting: Switch screen or confirm setting changes	Switch-A*1	When riding: Switch between automatic and manual gear shifting

*1 Only when the assist bicycle supports automatic gear shifting.



- This manual uses default settings for all explanations regarding the function assignment of the switch unit. The functions assigned to switches can be changed from those described here, by connecting to E-TUBE PROJECT. Please contact your place of purchase for details.
- The switch layout may differ according to the switch unit. Refer to the switch unit user's manual for details.

■ Notation method for operations

Subsequent operations using the main body button and switch unit of this product are indicated using the following notation.

Notation	Operation
<F>	Indicates an operation for pressing the function button.
<↑>	Indicates an operation for pressing the switch-X of the assist switch.
<↓>	Indicates an operation for pressing the switch-Y of the assist switch.
[Clock] (Example) Time setting	Items displayed on the cycle computer screen are enclosed in square brackets in this manual. When this notation is used in a procedure, it indicates an operation for selecting a display on the screen and pressing the function button or the switch-A of the assist switch to switch the screen or confirm the setting.
<A>	Indicates an operation for pressing the switch-A of the assist switch.



- Operations indicated with <F> may be performed with <A> instead.

Installing and removing the cycle computer

This product can be easily removed from the bicycle.




- If it cannot be easily removed with the procedure indicated here, or if you want to secure the product to prevent it from being easily removed, please contact your place of purchase.

■ Removing

1. Slide out the cycle computer.
 - Slide the cycle computer to the front while pushing the bracket lever down to remove it.

NOTICE

- This product does not operate when removed from the bicycle. The power turns OFF immediately, even if the power button is pressed.




■ Installing

1. Slide the cycle computer onto the bracket.
2. Insert the cycle computer securely until it clicks into place.

NOTICE

If the cycle computer is not correctly installed, the assist function will not operate normally.



Basic operation


■ Turning the power ON/OFF

When the power is turned ON with this product installed to the bicycle, all components connected to the drive unit are also turned ON (such as assist driving, the electronic gear shifting mechanism, and the lights).

NOTICE

- Check the following prior to turning the power ON.
 - The battery is firmly attached to the battery mount (refer to the "SHIMANO STEPS Special Battery and Parts User's Manual").
 - The cycle computer is firmly attached to the bracket.
- The power cannot be turned ON while charging.
- Do not step on the pedal when turning the power ON/OFF. Doing so may cause a system error.
- The built-in battery of this product is charged while the system is running. If the charge is insufficient because of long-term storage, etc., charge the built-in battery using one of the methods below. It takes a maximum of 2 hours to charge the built-in battery.
 - Charge the built-in battery while the (main) battery is mounted on the bicycle. (Only when the component with the charging port is the BM-E6000 / BM-E6010 / EW-CP100. Refer to the "SHIMANO STEPS Special Battery and Parts User's Manual".)
 - * When the (main) battery is fully charged, charging of the built-in battery also stops automatically.
 - The power can be turned ON using the power button of the (main) battery. (Refer to the "SHIMANO STEPS User's Manual" and "SHIMANO STEPS Special Battery and Parts User's Manual".)
 - * The power automatically turns OFF if the bicycle is stopped for 10 minutes. When charging for more than 10 minutes, operate any switch on the bicycle or turn the crank to keep the system running.
 - This product can be charged by connecting to the PC version of E-TUBE PROJECT. Make a request to the place of purchase.

1. Hold the power button down until the screen turns on.



- If the bicycle is left unused for 10 minutes after turning the power ON, the power automatically turns OFF (auto power OFF function).

When the main power is turned ON, a screen similar to that shown below is displayed, and then switches to the main screen.

Normal startup




Battery level too low



* The level of the cycle computer's built-in battery is too low.

■ Viewing the screen

The items displayed on the main screen differ according to the assist bicycle.



(A)	Battery level indicator (Refer to "Battery level indicator")	(E)	Automatic / manual gear shifting *4 *5 [Auto]: Displayed for automatic gear shifting. [Manual]: Displayed for manual gear shifting.		
(B)	Maintenance alert Indicates that maintenance is required. Contact your place of purchase or a distributor if this icon is displayed.	(F)	Assist gauge Displays the assist strength. A mode that provides stronger assistance the longer the length of the displayed gauge.		
(C)	Gear position display *1		(G)	Current assist mode *5 The assist modes that can be selected differ according to the assist bicycle.	
		Current gear position		(H)	Current speed
		Start mode gear position *2		(I)	Current time
(D)	Travel data display The traveling data that can be displayed differs according to the assist bicycle. (Refer to "Switching the traveling data display".)		(J)	Light icon Indicates that the light connected to the drive unit is lit.	
			(K)	Bluetooth® LE icon Displayed when an external device is connected over Bluetooth® LE. (Refer to "Bluetooth® LE connection")	

*1 Only displayed for electronic gear shifting.

*2 Only displayed for specifications that enable the start mode to be set. (Refer to "Setting the gear position when starting from a stop [Start mode]").)

3 Only displayed for manual gear shifting. (Refer to "Indicating the optimal gear shifting timing via an icon [Shifting advice].")

*4 For bicycles that cannot switch between auto and manual gear shifting, the display is fixed to [Auto] or [Manual].

*5 Refer to the SHIMANO STEPS user's manual.

Battery level indicator

The battery level is shown as an icon.

Display	Battery level
	100 - 81%
	80 - 61%
	60 - 41%
	40 - 21%
	20 - 1% *
	0%

* The battery level indicator will flash when the battery level is low.



- The cycle computer uses zero to indicate a battery level where assistance cannot be performed. With the SHIMANO STEPS system, the light can still be lit up for a while when assist stops due to a low battery. Therefore, the above-mentioned battery level may differ from that which can be checked on the battery.



■ Turning the light ON/OFF

If a light is connected to the drive unit, this product can be used to operate the light.

1. Press the light button.

- Lights are turned on.
- To turning off the lights, push the button again.

* When the battery powered light is not connected and [Backlight] is set to [MANUAL], pressing the light button turns the cycle computer's backlight on and off.



-
- The light power is linked with the main power. The light cannot be turned ON when the main power is OFF.
-

■ Switching the traveling data display

The traveling data that can be displayed differs according to the assist bicycle.

1. On the main screen: <F>



The traveling data switches in the following order each time <F> is pressed.

Display item	Explanation
[DST]	Traveling distance
[ODO]	Cumulative distance
[RANGE]	Traveling range *1
[RANGE]	Traveling range for each assist mode *1 *2 *3
[TIME]	Traveling time *3
[AVG]	Average speed *3
[MAX]	Maximum speed *3
[CADENCE]	Crank rotation speed *3*4

*1 Reference value. The value is displayed when the assist mode is set to a value other than [OFF] or [WALK]. The battery level cannot be displayed while this is being shown.

*2 It is displayed as shown in the figure. The gear position cannot be displayed while this is being shown.

RANGE	
HIGH	61 km
NORM	77 km
ECO	97 km

*3 Whether to show this or not can be set with E-TUBE PROJECT.

*4 It is displayed when the assist mode is set to a value other than [OFF] or [WALK] with electronic gear shifting.



• If the traveling data display that can be displayed is repeatedly switched, it will eventually switch back to displaying [DST].

Resetting the traveling distance

The traveling distance is reset from the main screen. When the traveling distance is reset, [TIME] (traveling time), [AVG] (average speed), and [MAX] (maximum speed) will also be reset.

The traveling distance can also be reset from the setting menu. Refer to "Resetting the settings [Clear]".

1. On the main screen: <F> (switches the traveling data display to [DST])



2. <F> (continue to hold until the number displayed for [DST] flashes)

3. When the number displayed for [DST] flashes: <F>
The traveling data is reset.



- If nothing is done for five seconds after the number for [DST] begins flashing, it will stop flashing and the screen will return to the main screen.

Setting menu

The items that can be set differ according to the assist bicycle. If assist switch is not connected, the setting menu cannot be displayed.

■ Switching to the setting menu

To display the setting menu, perform the following operation when the traveling data display is something other than [DST].

1. Stop the bicycle ⇒ <F> (continue to hold until the screen switches)



- You can also use the following methods to display the setting menu.
 - Stop the bicycle ⇒ <A> (continue to hold until the screen switches)
 - Stop the bicycle ⇒ <↑> + <↓> (continue to hold until the screen switches)

■ Returning to the main screen from the setting menu screen [Exit]

Closes the setting menu and returns to the main screen.

1. Setting menu screen ⇒ [Exit]

■ Setting the time [Clock]

1. Setting menu screen ⇒ [Clock] ⇒ <↑> or <↓> to change the "Hour" number ⇒ <F>
The cursor moves to the "Minute" number.



2. <↑> and <↓> to change the "Minute" number ⇒ <F>
The display will automatically return to the setting menu screen.



-
- Continue to hold <↑> or <↓> to change the number quickly.
-

■ Turning the operation sound ON/OFF [Beep]

Set whether to emit the operation sound.

1. Setting menu screen ⇒ [Beep] ⇒ [ON] / [OFF]
The display will automatically return to the setting menu screen.



-
- The beep sound for operation mistakes and system errors cannot be turned OFF.
-

■ Setting the display

Backlight setting [Backlight]

Configurable items	Details
[ON]	Always turned on
[OFF]	Always turned off
[MANUAL]	The backlight will turn ON/OFF when the light connected to the drive unit is turned ON/OFF. If no light is connected, the backlight can be turned ON/OFF by operating the cycle computer's light button.

1. Setting menu screen ⇒ [Backlight] ⇒ [ON] / [OFF] / [MANUAL]
The display will automatically return to the setting menu screen.

Setting the screen brightness [Brightness]

1. Setting menu screen ⇒ [Brightness] ⇒ <↑> or <↓> to adjust the brightness ⇒ <F>
The display will automatically return to the setting menu screen.



Switching the font color [Font color]

1. Setting menu screen ⇒ [Font color] ⇒ [White] / [Black]
The display will automatically return to the setting menu screen.

Switching the display language [Language]

1. Setting menu screen ⇒ [Language] ⇒ select the display language ⇒ <F>
The display will automatically return to the setting menu screen.

Changing the unit of the speed and distance [Unit]

Select the unit for displaying the speed and distance.


1. Setting menu screen ⇒ [Unit] ⇒ [km] / [mile]
The display will automatically return to the setting menu screen.

Matching the displayed speed with another device [Display speed]

You can adjust the displayed value when there is a difference between the speed displayed on this product and the speed indicator of another device.

Setting items	Explanation
Increase value	Increases the displayed speed value.
Decrease value	Decreases the displayed speed value.

1. Setting menu screen ⇒ [Display speed] ⇒ <↑> or <↓> to adjust the value ⇒ <F>
The display will automatically return to the setting menu screen.



- This setting only changes the displayed value. It does not change the power assist function.

Resetting the settings [Clear]

Resets the traveling distance and settings. When the traveling distance is reset, [TIME] (traveling time), [AVG] (average speed), and [MAX] (maximum speed) will also be reset.

Configurable items	Details
[Exit]	Return to setting menu.
[DST]	Reset the traveling distance.
[Default]*	Resets the settings.

*When the settings are reset, the following will be reset to their default settings.

- [Backlight]: [ON]
- [Beep]: [ON]
- [Unit]: [km]
- [Language]: [English]
- [Brightness]: [3]
- [Font color]: [White]

1. Setting menu screen ⇒ [Clear] ⇒ [DST] / [Default]

The display will automatically return to the setting menu screen.

■ Setting the assist bicycle function


Setting the gear position when starting from a stop [Start mode]

Automatically shifts to the set gear position when the bicycle starts from a stop.

Setting items	Explanation
[OFF]	Do not set the start mode.
[1], [2],...*1	Select the gear position.

*1 A gear position up to the maximum gear position of the shifting unit installed to the assist bicycle can be set.

1. Setting menu screen ⇒ [Start mode] ⇒ <↑> or <↓> to select the gear position ⇒ <F>
The display will automatically return to the setting menu.



Dynamically changing the riding comfort [Assist customize]

The riding comfort of the assist bicycle differs greatly according to the maximum torque of the drive unit and how much assistance is provided for pedaling. This product has multiple recommended settings registered that can be switched according to your preference. Details of the settings can be checked with E-TUBE PROJECT and the settings can be customized. Refer to the user's manual for E-TUBE PROJECT for details.

Setting items	Explanation
[Profile 1]	Changes to the riding comfort registered in [Profile 1].
[Profile 2]	Changes to the riding comfort registered in [Profile 2].

1. Setting menu screen ⇒ [Assist customize] ⇒ [Profile 1] / [Profile 2]

NOTICE

Depending on the setting, battery consumption may increase and the assisted traveling range may greatly decrease.



- The settings may differ according to the assist bicycle. Refer to the manual for the assist bicycle.

Indicating the optimal gear shifting timing via an icon [Shifting advice]

Performing gear shifting in addition to changing the assist mode enables more comfortable driving. Actively performing gear shifting without relying on only changing the assist mode can also reduce battery consumption. The gear shifting advice function uses an icon to notify you of the recommended timing at which to perform gear shifting, based on the bicycle riding conditions. The display timing can be adjusted in [Shift timing].

Configurable items	Details
[ON]	Enables the gear shifting advice function, which displays an icon to notify the user of the recommended timing for gear shifting during manual gear shifting.
[OFF]	Disable the shifting advice function

1. Setting menu screen ⇒ [Shifting advice] ⇒ [ON] / [OFF]

The display will automatically return to the setting menu screen.

Adjusting auto gear shifting [Shift timing]


Adjusts the gear shifting timing during automatic gear shifting.

Also sets the timing at which gear shifting advice is displayed.

Setting items	Explanation
Increase value	Increase the value when pedaling feels too heavy.
Decrease value	Decrease the value when pedaling feels too light.

1. Setting menu screen ⇒ [Shift timing] ⇒ <↑> or <↓> to adjust the value ⇒ <F>

The display will automatically return to the setting menu.



Wireless connection

This product has a wireless communication function.

■ 2.4 GHz digital wireless systems

2.4 GHz frequency digital wireless technology is the same thing as a wireless LAN. In rare instances, strong electromagnetic waves or electromagnetic interference due to the following locations or devices may impact communication.

- TVs, PCs, radios, motors/engines, or inside vehicles or trains
- Near railroad crossings and tracks, television transmitter stations, and radar stations
- Other wireless computers or digital control lights

■ ANT connection

All the information displayed on the main screen can be sent to an external device that supports ANT connections.

Connection method

When the main power is turned ON for SHIMANO STEPS, communication can be received at any time. Refer to the manual of the external device, switch the external device to connection mode, and then connect it.

■ Bluetooth® LE connection

All the information displayed on the main screen can be sent to an external device that supports Bluetooth® LE connections. The smartphone version of E-TUBE PROJECT may be used if a Bluetooth® LE connection is established with a smartphone. E-TUBE RIDE can be used to check traveling data on a smartphone connected over Bluetooth® LE.

Connection method

Communication can only be received under the following conditions. Refer to the manual of the external device, switch the external device to connection mode, and then connect it.

- Within 30 seconds of the main power for SHIMANO STEPS turning ON
- Within 30 seconds of operating any button/switch other than the SHIMANO STEPS power switch

■ Wireless system specifications

Model name	SC-E6100
Frequency band	2,402 - 2,480 MHz
Maximum high-frequency output	+4 dBm
Firmware version	4.0.0 or later

■ E-TUBE PROJECT

E-TUBE PROJECT is needed to change the setting of the SHIMANO STEPS and to update firmware. Download E-TUBE PROJECT from our support website (<https://bike.shimano.com/e-tube/project.html>). For information on how to install E-TUBE PROJECT, check the support website.

NOTICE

Do not connect to a device while the battery is being charged.



- Firmware is subject to change without notice.

Items configurable in E-TUBE PROJECT

The items that can be set differ according to the assist bicycle. Refer to the user's manual for E-TUBE PROJECT for details.

- The functions assigned to each operation switch can be changed.
- The settings that can be configured from this product can also be configured from E-TUBE PROJECT.
- Riding comfort settings for the assist bicycle can be retained and registered in this product. (Refer to "Dynamically changing the riding comfort [Assist customize]")

■ Recovering from the RD protection function [RD protection reset]

In order to protect the system from falls etc., the RD Protection function will operate when the rear derailleur is subjected to a strong impact. The connection between the motor and the link will be momentarily severed so that the rear derailleur can no longer operate.

When RD Protection Reset is run, it will restore the connection between the motor and the link, and recover the rear derailleur from RD Protection.



- This function is enabled for electronic gear shifting rear derailleur models only.

1. Setting menu ⇒ [RD protection reset] ⇒ [OK]

An illustration of a crankset is displayed on the screen.

2. Turn the crank clockwise with the rear wheel lifted up.

The rear derailleur moves, and the connection between the motor and link is restored.



■ Gear shifting adjustment with the electronic gear shifting unit [Adjust]

If gear shifting feels abnormal, contact the place of purchase.

■ Error/warning indication

Error indication

If an error code "E****" (where *** is letters or numbers) is displayed on the entire screen, the product may have malfunctioned.

Refer to the "SHIMANO STEPS Special Battery and Parts User's Manual" and follow one of the procedures below to reset the display.

- Press the battery power button to turn the power OFF.
- Remove the battery from the battery mount.



NOTICE

- If the situation does not improve even after turning the power back ON, consult with the place of purchase or a distributor as soon as possible.

Warning indication

If a warning code "W****" (where *** is letters or numbers) is displayed on the screen, the product may have a temporary problem.

If the situation is improved, this indication will disappear. If the situation does not improve, contact the place of purchase as soon as possible.



- The PC version of E-TUBE PROJECT (V4 or later) classifies errors and warnings into more detailed categories according to the cause. For this reason, the error/warning codes that are displayed in the PC version of E-TUBE PROJECT may differ from those displayed on this product, E-TUBE RIDE, or the smartphone version of E-TUBE PROJECT.

For details on error/warning codes, check the latest versions below:



<https://si.shimano.com/iER/STP0A>

■ When a problem occurs

Symptoms	Possible cause	Remedy
The cycle computer does not start when the power button is pressed.	Is the battery charging?	When charging with the battery installed to a bicycle, you cannot start the system. The screen continues to display the SHIMANO STEPS logo.
	The level of the cycle computer's built-in battery is too low.	Refer to the "SHIMANO STEPS Special Battery and Parts User's Manual" to start the system using the (main) battery power button or satellite system on/off switch. For information on charging the built-in battery of the cycle computer, refer to "Turning the power ON/OFF".
The system does not start when the (main) battery power button is pressed.	The (main) battery level may be too low.	Refer to the "SHIMANO STEPS special battery and parts user's manual" to charge the battery, and then turn the power ON again.
	Is the power ON?	Refer the "SHIMANO STEPS special battery and parts user's manual" to turn the power ON.
	Is the battery charging?	When charging with the battery installed to a bicycle, you cannot start the system. The screen continues to display the SHIMANO STEPS logo.
	Is the connector of the electric wire installed correctly?	Check whether the connector of the electric wire is disconnected. If you are not sure, contact the place of purchase.
	A product that the system cannot identify may be connected.	Contact the place of purchase.
The gear position is not displayed.	The gear position is only displayed when the electronic gear shifting unit is installed.	Check whether the connector of the electric wire is disconnected. If you are not sure, contact the place of purchase.
I want to turn the operation sound OFF.		Refer to "Turning the operation sound ON/OFF [Beep]".
Cannot start the setting menu while riding.	The product is designed to prevent the setting menu from being started while riding is detected. This is normal.	Configure the settings after stopping.
A switch operation cannot be performed and two beeps are heard.	Operation of the switch you pressed is prohibited.	This is not a malfunction.
Three beeps are heard.	An error or warning has occurred.	An error or warning is displayed on the cycle computer. Refer to "Error/warning indication".
The gear position set in the start mode is not set when the bicycle is stopped.	You may have pressed the pedal too strongly.	Pressing the pedal gently makes it easier to shift gears.

SHIMANO

SHIMANO NORTH AMERICA BICYCLE, INC.

One Holland, Irvine, California 92618, U.S.A. Phone: +1-949-951-5003

SHIMANO EUROPE B.V.

High Tech Campus 92, 5656 AG Eindhoven, The Netherlands Phone: +31-402-612222

MADISON (A DIVISION OF H.YOUNG (OPERATIONS) LTD)

Roebuck Way, Knowlhill, Milton Keynes, Buckinghamshire, MK5 8HL, United Kingdom

SHIMANO INC.

3-77 Oimatsu-cho, Sakai-ku, Sakai City, Osaka 590-8577, Japan

Please note: specifications are subject to change for improvement without notice. (English)

© Feb. 2021 by SHIMANO INC. ITP